



**CHEVROLET CRUZE  
2010-2014  
BUICK VERANO  
2012-2013**

**15963 MT**

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: **2000** LBS. TRAILER WEIGHT & **200** LBS. TONGUE WEIGHT.  
\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\*

PARTS LIST/LISTE DE PIÈCES

Num	QTY	DESCRIPTION	Num	QTY	DESCRIPTION
1	4	10 mm X 40 mm X 1.75 HEX BOLT (1)	7		
2	4	LOCK 3/8 (2)	8		
3	4	FLAT 3/8 (3)	9		
4	2	FLAT NUT WITH WIRE 10 mm 3/4 (4)	10		
5	2	FLAT NUT 10 mm 3/4 (5)	11		
6			12		FILAGE SUGGÉRÉ/ WIRING: 74209



## ÉTAPES D'INSTALLATION / INSTRUCTIONS :

- 1- INSERT THE FLAT NUT WITH WIRING INTO THE FIRST HOLE OF THE FRAME AGAINST THE BUMPER
- 2- FIX THE HITCH AT THIS PLACE
- 3- INSERT THE FLAT NUT IN THE REAR HOLES OF THE FRAME
- 4- THIGHTEN WELL

- 1- INSÉREZ LES FLAT NUT AVEC BROCHE DANS LE PREMIER TROU DU CHÂSSIS CONTRE LE PARE-CHOC
- 2- FIXEZ L'ATTACHE À CETTE ENDROIT
- 3- INSÉREZ LES FLAT NUT DANS LES TROUS ARRIÈRES DU CHÂSSIS
- 4- BIEN SERREZ

SRG trailer hitches., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, SRG trailer hitches Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. SRG trailer hitches Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.