



20085
20085 MT

2000 LBS

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: **2000 LBS.** TRAILER WEIGHT & **200 LBS.** TONGUE WEIGHT.
DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

PARTS LIST/LISTE DE PIÉCES

Num	QTY	DESCRIPTION	Num	QTY	DESCRIPTION
1	4	HEX BOLT 8 X 45 X 1.25	7		
2	4	LOCK WASHER 5/16	8		
3	4	FLAT WASHER 5/16	9		
4			10		
5			11		
6			12		



INSTALLATION : 1: Enlever le recouvrement du pare-choc. 2: Enlever les boulons sous le véhicule image 4. 3: Dévisser les boulons d'origine tel qu'indiqué sur les images 1 . 4: Enlever les deux boulons de l'image 2 garder les boulons. 5: Mettre l'attache en place fixer l'attache avec les boulons fournis . 6 Enlever le support central du pare-choc photo 3 . 7: pour le modèle 20085 faire une découpe de 3po1/2 au centre du morceau sous le véhicule photo 5. (pour le modèle 20085 mt faire une découpe de 2po1/2 au centre du morceau.) 8 Remonter le pare-choc .

SRG trailer hitches., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, SRG trailer hitches Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. SRG trailer hitches Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.